



SECTION A-A

GENERAL NOTES

1. PLACE PAVERS IN PATTERNS PER CITY OF FRANKLIN STREETSCAPE PLANS. PLACE PAVERS WITH HAND TIGHT JOINTS (MAX 1/16"). USE 4" X 8" PAVERS AS SHOWN. SAW CUT PERIMETER PAVERS ABUTTING CONCRETE PAVEMENT ONLY AS NEEDED TO FILL VOIDS. SEE CITY OF FRANKLIN PAVER SPECIFICATIONS FOR INSTALLATION.
2. DO NOT USE FILLERS TO FILL JOINT VOIDS OF EXCESSIVE WIDTH BETWEEN THE BRICK PAVERS AND THE ABUTTING CONCRETE PAVEMENT. CUT PAVERS TO FIT.
3. INSTALL CONCRETE PAVEMENT JOINTS AND REINFORCMENT BARS IN ACCORDANCE WITH LANS AND DETAILS AND SECTION A-A
4. THIS DETAIL TO BE USED IN DOWNTOWN FRANKLIN GATEWAY CORRIDORS AND CONNECTOR STREETS.

N.T.S

**CITY OF FRANKLIN**

CROSS WALK 2 3/4" THICK BRICK PAVERS ON CONCRETE BASE

**DWG. NO. SS-1**

EFFECTIVE DATE: 7/1/2017

*Paul P. Hoyle* 7/1/2017  
CITY ENGINEER DATE

*Stephanie M. Martin* 7/1/2017  
ASST. DIRECTOR OF ENG. DATE