

Sound System Quick Start

1) Turn on speaker(s). Power button is located on bottom left corner of control side.

Speakers are battery or AC powered.

2) Power on wireless receiver and verify channel 05.

3) Power on main control head.

4) Select "Sd" by using *MODE*.

5) Hit *REP/ID3* once to place on repeat.

6) Hit *PLAY* to start music.

7) Adjust *VOLUME* for the music using

the volume control to the right of

PLAY.

8) Power on wireless Mic and test connectivity. Adjust the volume to appropriate

level by turning the small dial on the wireless receiver as shown in the picture.

***If both speakers are needed, attach them via the long aux cable. Plug one end into

the LINE OUT and the other end into Speaker 2's AUX IN.***

